

Alarm Tender™

“Keep Your Smoke Alarms Alive!”

The Situation

Research shows that many fatal house fires occur in homes without working smoke alarms.

Many homes don't have the proper number of smoke alarms to provide optimal protection.

Smoke alarms work best and fastest when mounted high where the smoke rises first.

Unfortunately, many people find it difficult to reach the alarm to change batteries, clean the alarm and perform the monthly tests or frequent fire drills.

In addition, batteries are often not readily available for immediate replacement. Sometimes the alarms' batteries are borrowed for other tools and toys.

Many fires start near wood stoves or in the kitchen, but since wood smoke and cooking can cause false alarms, people often do not have smoke alarms in these areas.

Injuries sometimes occur when people fall while climbing on chairs or ladders to change batteries or hush nuisance alarms.

Some existing smoke alarms are intentionally disabled when they become nuisances, with chirping weak batteries or false alarms.

People in wheelchairs, the elderly, and vertically challenged people all experience difficulty maintaining smoke alarms. And tragically, these same people often need more time to escape a fire.

Accessible 

Alarm Tender™

“Don't gamble with your life” 

The Smart Solution

Easily attached to a wall, Alarm Tender™ can position the smoke alarm in the proper location, AND also enable a person to simply slide the alarm down to “hush” the alarm, change the battery, perform family fire drills and the recommended frequent testing.

A spare battery can be stored in the base of Alarm Tender™, keeping the spare battery available and preventing “borrowing” of the alarm's battery for other tools and toys.

Alarm Tender™ is great to use in open stairwells, where attempting to reach the smoke detector can be very dangerous.

Almost anyone can mount Alarm Tender™ permanently and quickly on a wall using the self adhesive tape attached to its base and/or the screws (included).

Alarm Tender™ can be attached using only the screws, and then be removed and taken to a new location.

If the user wishes, the Alarm Tender™ can also be mounted to the side of a wooden doorframe with the optional Alarm Tender™ Door Frame Attachment Bracket.

Even in apartments, dormitories, and homes with hard-wired smoke detectors, battery alarms are recommended as additional security measures.


Lightweight decorations can be mounted on Alarm Tender™, enabling it to fit right into any room. And remember, the decorations will slide down along with the Alarm Tender™ so changing decorations is safe and simple too.

Seasonal decorations can remind the user to test the smoke alarm frequently.

Visit www.alarmtender.com for more info.

AlarmTender™

"Keep Your Smoke Alarms Alive!"



A new way to make your home and family safer...

www.alarmtender.com
patent pending

Made in the USA by:
Angel Inventions, Inc.
PO Box 236
Dauphin, PA 17018-0236
(717) 921-2645

©2008 Angel Inventions, Inc.



Alarm Tender™

"Keep your smoke alarms alive!"

Easy to install:

1. mount smoke alarm to Alarm Tender
2. peel backing from mounting tape
3. push Alarm Tender against wall
4. slide the smoke alarm down . . .

**Now you can
reach your
battery powered
smoke alarms!**

Be sure to follow all local fire and building codes when installing smoke alarms. Read installation directions carefully.

www.alarmtender.com

Made in the USA by Angel Inventions, Inc. 717-921-2645

© 2008 smoke alarms not included